



Installation Instructions

717830

2015-16 DODGE CHALLENGER R/T 5.7L ENGINE

Removal:

Rev. 3/2/2020

- 1) Raise vehicle and support securely with stands. To ease the removal of the stock system, spray a penetrating lubricant onto the rubber hangers.
- 2) At the rear of each tailpipe, there is a clamp that secures the factory stainless tip to the mufflers. Use a 15mm wrench to loosen and remove the factory tip. After the tip has been removed you must also remove the clamp from the muffler. The clamp is tack welded in one place and must be wiggled loose. The tips and clamps will be reused with the Flowmaster system.
- 3) Using a 13mm socket unbolt the left tailpipe assembly at the flanged connection at the rear of the muffler. Slide the three hanger rods out of the rubber mounts on the vehicle and remove the left tailpipe assembly.
- 4) Support the right side muffler with a stand, then using a 15mm socket, loosen the clamps at the slip fit connections behind the catalytic converters. Remove the three remaining hanger rods from the rubber mounts on the vehicle and slide the system back off of the head pipes.

Installation:

- 1) Before installing anything, prep the clamps supplied in the hardware kit by removing the nuts, and applying a thick lubricant such as white grease or anti-seize to the threads.
- 2) Begin by placing a supplied **#MC250BS** clamp onto each of the slip fits of Scavenger pipe **#86306M**. Then place the Scavenger pipe onto the back of the stock head pipes (make sure the Flowmaster embossing is facing the ground). Level and center the assembly in the drive line tunnel and support with a stand. Tighten the two clamps enough to hold but still allow for adjustment.
- 3) Place a supplied clamp onto the inlet of each **#71226-Z** muffler. Then slide the mufflers onto the back of the Scavenger pipe assembly 1 3/4" and support with stands. Level the mufflers and tighten the clamps enough to hold but still allow for adjustment.
- 4) Place a supplied clamp onto the left muffler outlet, place the left tailpipe **#86310M** into position and starting from the rear, connect the hangers on the tailpipe to the rubber mounts on the vehicle. Then slide the tailpipe into the muffler outlet. Adjust the tailpipe so that all hangers are level and tighten clamp enough to hold but still allow for adjustment. Repeat this step for right tailpipe **#86311M**.

- 5) Adjust the position of all the pipes and mufflers to provide a satisfactory fit. A minimum of 1/2" clearance around all parts of the system must be maintained; while keeping suspension travel and vibration in mind. After adjustments have been made, you may now securely tighten all clamps.
- 6) Re-attach the factory stainless tips to the back of each tailpipe using the clamps previously removed. Adjust the position of the tips and tighten the clamp securely.
- 7) After the system is secure, slide the 7/16" hanger keepers onto the ends of the hangers located at the rear of the vehicle. These will prevent the hangers from slipping out of the rubber mounts.
- 8) For a more secure installation, we recommend welding all slip-fit connections.

PACKING LIST		
Qty.	Description	Part #
1	Scavenger Assembly	86306M
2	Muffler	71226-Z
1	Left Tailpipe Assembly	86310M
1	Right Tailpipe Assembly	86311M
1	PARTS KIT (includes the following)	PK508
6	• 2 1/2" Band Clamp	MC250BS
6	• 7/16" Hanger Keeper	HW502



Installation Diagram
717830
2015-16 DODGE CHALLENGER R/T
5.7L ENGINE

