



Installation Instructions
718146
 2021-23 FORD BRONCO TWO-DOOR
 WITH 2.3L & 2.7L ENGINE

OVERVIEW:

1. Take a moment to read and understand these instructions before installing your Flowmaster performance exhaust.

NOTES

- Before starting, use the parts list and drawing to verify your kit's contents. In the unlikely event that any parts are missing, please contact Flowmaster Technical Support for replacements.
- Instruction photos show installation of a similar kit on a 4-door Bronco. But the removal and installation procedures are identical, and the parts list and drawing are correct for the 2-door kit.

ITEM	PART NO.	DESCRIPTION	QTY.
1	26905M	INLET PIPE ASSY	1
2	26906M	MID PIPE ASSY	1
3	70009-595	FLOWFX MUFFLER ASSY	1
4	529HA	RIGHT HANGER ASSY	1
5	530HA	LEFT HANGER ASSY	1
6	MC300BS	CLAMP, STAINLESS, 3"	2
7	HA168	HANGER, RED RUBBER	2
8	HW208	BOLT, 3/8-16 x 1"	2
9	HW103	NUT, 3/8-16	2
10	HW303	FLAT WASHER, 3/8"	2
11	HW309	LOCK WASHER, 3/8"	3
12	HW502	HANGER KEEPER, 7/16"	4
13	HW503	HANGER KEEPER, 1/2"	1
14	3401401	LOCK NUT, M8 x 1.25	2
15	HW274	BOLT, SHLDR 1/2"D x 3/4"L, 3/8-16	1

REMOVE STOCK EXHAUST SYSTEM:


2. Raise vehicle up on a hoist or rack to working height. If you don't have access to a hoist or rack, support vehicle with jack stands.

WARNING

Avoid serious burns! Allow your vehicle time to cool completely before touching any factory engine components.

To ease preparation and installation of your new kit:

- Apply penetrating lubricant to mounts, bolts and clamps before you remove them.
- Use stands as necessary to support parts as you detach them from your vehicle and again as you install new parts.




3. Support exhaust then dismount muffler from isolators. Loosen clamp from inlet then remove muffler from vehicle. Dismount isolators from factory mounts.



4. Support the front pipe, then remove the flange fasteners. Unbolt the isolator mount from frame, separate rear wire hanger from isolator, then remove front pipe from vehicle.

NOTE orientation of isolator mount, and retain flange fasteners, gasket, and isolator mount screws for use at re-installation.



INSTALL FLOWMASTER EXHAUST SYSTEM:

5. Apply anti-seize compound to all threaded fasteners, to prevent galling, seizing and corrosion.

NOTE: This image is for illustration purposes only. It doesn't necessarily reflect all the hardware included in your kit.




- Fasten the isolator mount to the **inlet pipe (1)** with **shoulder bolt (15)** and **lock washer (11)**. Place the stock gasket between the flex pipe and inlet pipe flanges, fasten the inlet pipe to the flex pipe with the stock screws, and fasten the isolator mount to the vehicle frame.



NOTE: Fasten the parts to the vehicle with the stock fasteners removed at Step 4.




- Place **clamp (6)** onto the **mid pipe (2)**, situate the pipe over the axle, and connect it to the inlet pipe. Snug the clamp just enough to allow adjustment during system assembly.



- Fasten the **right hanger (4)** to the passenger-side frame studs with **2 lock nuts (14)**. Fasten the **left hanger (5)** to driver-side frame using **2 bolts (8)** and **flat washers (10)** inside the frame, and **2 lock washers (11)** and **nuts (9)** against the hanger. Install the **2 rubber hangers (7)** on the hanger rods.



9. Place **clamp (6)** onto **muffler (3)**, and connect the muffler to the mid pipe. Insert the muffler's wire hangers in the rubber hangers, and snug the clamp just enough to allow for adjustment.



10. Adjust the fit of all exhaust components, maintaining 1/2" clearance and allowing for suspension travel and vibration. Then tighten both clamps. Finally, install the 5 **hanger keepers (12 & 13)** onto each wire hanger.
11. RECOMMENDED: Secure the slip-fit pipe connections with a 1-inch tack weld, then spray the welds with high-temp paint to prevent premature corrosion.



Congratulations, the installation of your FLOWMASTER performance exhaust system is now complete!



