

## Installation Instructions 817493 **1997-99 JEEP WRANGLER TJ** 2.5L & 4.0L ENGINE

Rear Wheel & Four Wheel Drive

Raise the vehicle up on a hoist or rack to working height. 1)

Rev. 3/26/2020



Using a hacksaw or sawsall, cut the stock tailpipe off where it exits the 2) muffler. (This step is not mandatory, but it makes removal a little easier.)



Separate the wire hangers on the tailpipe from the rubber mounts on the 3) vehicle. Remove the tailpipe and set aside.



Support the muffler with a stand. Using a 15mm wrench, remove the muffler 4) clamp at the catalytic converter to muffler connection. Remove the muffler assembly from under the vehicle.



5) Place the provided 2<sup>1</sup>/<sub>4</sub>" clamp onto the muffler inlet and then slide the muffler onto the back of the catalytic converter and support with a stand. Tighten the clamp enough to hold, but still allow for adjustment.



Place a provided 21/2" clamp onto the muffler outlet and then place tailpipe 6) #16770S into position over the rear axle. Slide the hangers on the pipe into the rubber mounts on the vehicle and then into the muffler outlet. Tighten the clamp enough to hold, but still allow adjustment.



7) Adjust the position of all pipes and mufflers to provide a satisfactory fit. This is a tight fitting system, so take your time and be patient, tightening and adjusting a little bit at a time. Be sure to maintain an adequate clearance around all parts of the system to avoid rattles or damage to heat sensitive components. Once you're happy with the fit, tighten all connections down securely. For a cleaner appearance and more secure installation, we highly recommend welding all slip-fit connections.

## **PACKING LIST**

<u>Qty</u>	Description	Part#	
1 1 1 1	Muffler Assembly Tailpipe Parts Kit 2¼" Band Clamp	852462-268 16770S PK631	MC225BS
1 2	2½" Band Clamp 7/16" Hanger Keepe	r	MC250BS HW502



Installation Diagram 817493 1997-99 JEEP WRANGLER TJ 2.5L & 4.0L ENGINE Rear Wheel & Four Wheel Drive

